


TNT20



1、Input：

Socket provided for connecting electric bass guitar..

2、Compressor Switch：

Engages the on board compressor.

3、Gain：

This control is used to set the level of gain present in the pre-amp. The higher the level of gain, the more the signal will clip producing distortion.

The Gain control should be used in conjunction with the Volume control (7) to produce the desired signal characteristics.

4、Bass/Middle/Treble:

Controls the low mid and high frequency EQ in the preamplifier

5、Volume:

Sets the overall listening level of the amplifier.

6、CD IN:

Sockets for connection of external CD player.

7、Phone：

Sockets for connection of external headphones.

Connecting headphones automatically isolates the internal speaker.

8、Bluetooth

Mode touch: Play/Pause
Mode hold on: on/Off Bluetooth
Right touch: Next song
Right hold on: Volume increase
Left touch: Last song
Left hold on: Volume decrease

TECHNICAL SPECIFICATION

Power output：	30W/40W
Power Supply：	230VAC 50HZ/110VAC60HZ
Dimensions(H×W×D)：	348x356x210(mm)
System Hum and Noise：	≥70dB
Input impedance：	>1MΩ
Speakers impedance：	8ohms(6.5"/8")

1、輸入插孔(INPUT)

用于連接吉它

2、壓縮開關 (COMPRESSOR)

按下時可提高本放大器的壓縮量

3、增益調節(GAIN)

用于調節整機增益，增益越大越會產生失聲效果與Volume配合調節可產生所需要的音色

4、低音、中音、高音調節(BASS、MID、TRE)

用于調節低音區、中音區、高音區的提升/衰減量。

5、音量調節 (VOLUME)

用于調節整機音量。

6、CD輸入插孔(CD IN)

用于連接CD機、磁帶機及其它的輔助設備，使您可以在節目源的伴奏下獨自練習。注意此輸入插孔電平是固定的，您必須在接入的機器上進行音量調節。

7、耳機輸出插口(PHONE)

用于連接耳機，這時機內揚聲器連接會斷開。

8、藍牙模式 (BLUETOOTH)

MODE鍵单击：開始/暫停音樂播放
MODE鍵長按：打開/關閉藍牙功能
右边扭到底一下：切換到下一首歌曲
右边扭到底不放：音量增加
左边扭到底一下：切換到上一首歌曲
左边扭到底不放：音量減少

主要技術指標:

輸出功率:	30W/40W
電源:	AC220V 50HZ/AC110V 60HZ
外型尺寸(HXWXD):	348x356x210(mm)
信噪比:	≥70dB
輸入阻抗:	>1MΩ
揚聲器阻抗:	8ohms(6.5"/8")