


DA40 电鼓音箱



1.INPUT1

For connect of KEYBOARD, DRUM, GUITAR and so on instruments.

2.INPUT2

For connect of KEYBOARD, DRUM, GUITAR and so on instruments

3.VOL1

Sets the volume level for the INPUT1 channel.

4.VOL2

Sets the volume level for the INPUT2 channel.

5.BASS

Controls the low frequency in the machine.

6.TREBLE

Controls the high frequency in the machine.

7.LEVEL

Sets the volume level for the CD IN channel.

8.CD IN

Socket for connection of external CD player.

9.LINE OUT

Sockets for connection to a P.A. system.

10.POWER

Turns the machine on and off.

11. MP3 Player:

Can play Mp3 files store in USB or SD card, the Mode key can choose from USB or bluetooth

TECHNICAL SPECIFICATION

Power Output:	40W
Power Requirements:	230VAC50HZ/110VAC60HZ
Dimensions (H×W×D):	430×390×340(mm)
System Hum and Noise:	≥70dB
Input impedance:	>1MΩ
Speakers impedance:	4Ω(10" speaker)

1.輸入插孔1 (INPUT1):

連接鍵盤,電鼓,吉它等樂器信號

2.輸入插孔2 (INPUT2):

連接鍵盤,電鼓,吉它等樂器信號

3.輸入插孔1 音量調節 (VOL1):

控制輸入插孔一的音量

4.輸入插孔2 音量調節 (VOL2):

控制輸入插孔二的音量

5.低音調節 (BASS):

調節輸入一和輸入二的低音頻率

6.高音調節 (TREBLE):

調節輸入一和輸入二的高音頻率

7.CD音量調節 (CDIN):

用于調節外接音頻信號的音量

8.CD輸入 (CDIN):

用于連接外接音頻信號, 俗稱蓮花座

9.綫性輸出插口 (LINEOUT):

用于連接調音臺, 錄音設備

10.電源開關 (POWER):

用于交流電源的接通以及切斷

11. MP3播放器:

按鈕為上一曲鈕, 播放鈕, 下一曲鈕, USB 或藍牙選擇鈕。

主要技術指標:

輸出功率:	40W
電源:	230VAC50HZ/110VAC60HZ
外型尺寸(H×W×D):	430×390×340(mm)
信噪比:	≥70dB
輸入阻抗:	>1MΩ
揚聲器阻抗:	4Ω(10" speaker)